



MICRO POCKET THERMOMETER



Operating Instructions

INSTRUMENT OPERATION - Press the '⏻' button once to turn on the unit. Press the '⏻' button once again to turn off the unit. When powered on, all the LCD segments will light up for two seconds before displaying the temperature.

°C/°F - To switch from °C to °F, press the '⏻' button and hold for three seconds when turning the unit on.

BATTERY REPLACEMENT - Use a screwdriver to open the battery cover. Install the battery with the correct polarity. Close and tighten the battery cover.

BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.



ERROR MESSAGE - If the display shows 'Bat', the battery should be replaced with a CR1632 lithium coin cell battery. If the display shows 'LLL.L' the reading is outside of the lowest measurement range limit (-50 °C), or there is an open circuit in the sensor. If the display shows 'HHH.H' the reading is outside of the highest measurement range value (150 °C), or there is a short circuit in the sensor.

GUARANTEE - This instrument carries a one-year guarantee against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ETI, be either repaired or replaced without charge. The product guarantee does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within ETI's Terms & Conditions of Sale at etilt.com. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.



Supplied by
Electronic Temperature Instruments Ltd
Worthing · West Sussex · BN14 8HQ
01903 202151 · sales@etiltd.com · etiltd.com

